

AUDIO AND CONNECTIVITY

Learn how to operate the vehicle's audio system.

Basic Audio Operation


Connect audio devices and operate buttons and displays for the audio system.

■ USB Connection

Connect a USB flash drive or other audio device, such as an iPod® or iPhone®.

USB adapter cable*

1. Open the front pocket. Unclip the USB adapter cable.
2. Install the flash drive or cable connector to the USB adapter cable.



USB port*

1. Open the center console. Open the USB port cover.
2. Connect the device to the USB port.



iPod and iPhone are trademarks of Apple, Inc.

■ HDMI Port*

Connect an HDMI cable.

1. Open the center console. Open the HDMI port cover.
2. Insert an HDMI cable to the HDMI port.



Additional cables and connectors sold separately.

■ Auxiliary Input Jack*

Connect standard audio devices with a 1/8-inch (3.5 mm) stereo miniplug.


1. Open the center console. Open the AUX cover.
2. Connect the device to the input jack. Use the device to control the audio.



**if equipped*

■ Accessory Power Socket

Open the center console. Open the socket cover to use it when the vehicle is on.



NOTICE

Do not insert an automotive type cigarette lighter element. This can overheat the power socket.

■ Steering Wheel Controls

Operate certain functions of the audio system using the steering wheel controls.

MODE button: Cycle through available audio modes.

VOL buttons: Adjust audio volume.

CH buttons: Change presets, tracks, albums, or folders.

FM/AM/SiriusXM® Radio*

Press (+) or (-) for the next or previous station. Press and hold (+) or (-) for the next or previous strong station.

CD/HDD*/iPod/USB/Bluetooth Audio

Press (+) or (-) for the next or previous track. Press and hold (+) or (-) for the next or previous folder (CD/USB).

Pandora®*/Aha

Press (+) for the next song. Press and hold (+) or (-) for the next or previous station.




■ Adjusting the Sound

Adjust various sound settings using these two methods.

Models with one display

Use the selector knob to make and enter selections.

1. Press the SETUP button.
2. Select Sound Settings.
3. Select the setting you want, and adjust it to the desired level.
4. Press the BACK button to exit out of the menu.



Models with ODMD

Use the touchscreen to make and enter selections.

1. Select More.
2. Select Sound.
3. Select the item you want to adjust, and rotate to change it.
4. Press BACK to exit out of the menus.



Models with ODMD

Siri™ Eyes Free

Activate Siri through your vehicle when an iPhone is paired to the system. Visit www.acura.com/handsfreelink (U.S.) or www.acura.ca/siri (Canada) to check phone compatibility.

Back button: Exit Siri Eyes Free mode, or cancel a command.

Talk button: Press and hold to activate Siri Eyes Free mode. The Smartphone screen appears. Say your command after you hear the Siri tone. If you only press and release the Talk button, the standard voice recognition system is activated.



Here are some examples of Siri commands:

"Call John Smith"

"Remind me to pick up dinner"

"Read my new text message"

"Set up a meeting today at 3 p.m."

"Find a nearby sushi restaurant"

"Play song XYZ"

Notes:

- Any requests that include visual feedback from Siri on your phone are not displayed in the vehicle.
- Certain commands rely on the iPhone's features and existing apps.
- To hear turn-by-turn directions or songs through the vehicle, set the audio source to *Bluetooth Audio*.



Siri and iPhone are trademarks of Apple, Inc.

**if equipped*

Models with one display

Color Information Display


Use the buttons to control the display and audio system.



Models with one display

FM/AM Radio

Play FM or AM radio stations.




Models with one display

Compact Disc (CD) or USB Flash Drive

Insert a CD to begin playing. The audio system supports audio CDs, CD-Rs, and CD-RWs in MP3, WMA, or AAC formats.

Connect your USB flash drive using the USB adapter cable. The audio system supports MP3, WMA, or AAC files.



■ Searching for Music

Use the selector knob to search for tracks stored on the CD or USB drive.

1. Press the selector knob to enter the folder menu.
2. Select a folder or file.
3. Select the song you want to play.





NOTICE

Do not use CDs with adhesive labels or insert a damaged CD. Inserting these types of CDs may cause them to get stuck or damage the audio unit.

Models with one display

iPod®


Connect your device using the USB adapter cable.



■ Searching for Music

Use the selector knob to search for tracks stored on the iPod.

1. From the audio screen, press the selector knob to enter the iPod menu.
2. Select a search type (artist, album, track, etc.).
3. Select the song you want to play.





iPod is a trademark of Apple, Inc.

Models with one display

Bluetooth® Audio

Play streaming or stored audio from your compatible phone when it is paired to *Bluetooth HandsFreeLink*. Visit www.acura.com/handsfreelink (U.S.) or www.handsfreelink.ca (Canada) to check phone compatibility. Standard data rates may apply.



Notes:

- Make sure the volume on your phone is properly adjusted.
- You may need to enable additional settings on your phone for playback.
- The resume/pause function and remote audio controls are not supported on all phones.

Applicable laws may prohibit the operation of handheld electronic devices while operating a vehicle. Only launch streaming audio on your phone when it is safe to do so.

On-Demand Multi-Use Display (ODMD)

Operate the audio system using either the touchscreen or dashboard buttons.

The functions shown here can be used with most audio sources. Refer to subsequent audio pages for more specific functions. Options that appear depend on the selected audio source.

ODMD controls


Power/volume knob

Audio Source: Change the audio source. Select Edit Order to arrange audio icons to your preference.

Sound: Adjust sound settings.

Shortcuts (Audio tab): Store or select up to six AM, FM, or SiriusXM stations or HDD tracks.

More: Change screen and sound settings, or display menu options.



Audio buttons

BACK button: Return to the previous display.


☀️ button: Adjust the upper screen brightness.

Interface dial (from the audio screen): Move up, down, left, and right. Rotate and press ENTER to make selections in the upper display.

AUDIO button: Display the audio screen.

MENU button: Display menu items.

SETTINGS button: Choose Audio Settings.



FM/AM Radio

Play FM or AM radio stations.

Audio Source: Select the FM or AM icon.

Scan: Scan for stations with a strong signal.


Tune bar: Change the station.

Presets: To store a station, tune to the desired station, select Presets, and select and hold the desired preset number. Select a preset station once stored.




TAC*: Tag songs from HD Radio and store to a connected iPod or iPhone.

Skip/seek bar: Find a station with a strong signal.




Interface dial (from the Audio screen): Select from the station list or presets in the upper display.



SiriusXM® Radio

Available on a subscription basis only. For more information or to subscribe, contact your dealer or visit www.siriusxm.com (U.S.) or www.siriusxm.ca (Canada).



Audio Source: Select the SiriusXM icon.

Category bar: Change the category.

Scan: Scan for channels.


Presets: To store a station, tune to the desired station, select Presets, and select and hold the desired preset number. Select a preset station once stored.

TAG: Tag songs and store to a connected iPod or iPhone.

Play/pause

Skip/seek bar: Change the channel.

Interface dial (from the Audio Screen): Select from the category list, channel list, and presets in the upper display.





To learn about additional features—such as multi-channel preset, replay, or SportsFlash—see your Owner's Manual or Navigation Manual on the Owner Information CD or visit owners.acura.com (U.S.) or myacura.ca (Canada).

Compact Disc (CD) or USB Flash Drive

Insert a CD to begin playing. The audio system supports audio CDs, CD-Rs, and CD-RWs in MP3, WMA, or AAC formats.

Connect your USB flash drive using the USB adapter cable. The audio system supports MP3, WMA, or AAC files.



■ Searching for Music

Use the interface dial to search for tracks on the CD or USB.

1. From the audio screen, press MENU.
2. Select Music Search.
3. Select a search type (artist, album, track, etc.) or folder.
4. Select the song you want to play.





NOTICE

Do not use CDs with adhesive labels or insert a damaged CD. Inserting these types of CDs may cause them to get stuck inside or damage the audio unit.

Hard Disc Drive (HDD) Audio

When music CDs are inserted, they are automatically recorded by system default onto the built-in HDD for later playback.



■ Searching for Music

Use the interface dial to search for tracks using several methods.



1. From the audio screen, press MENU.
2. Select Music Search.
3. Select a search type (artist, album, track, etc.).
4. Select the song you want to play.



You can also search for and play HDD music using Song By Voice™.

iPod®

Connect your device to the USB port.



■ Searching for Music

Use the interface dial to search for tracks using several methods.

1. From the audio screen, press MENU.
2. Select Music Search.
3. Select a search type (artist, album, track, etc.).
4. Select the song you want to play.





On vehicles with navigation, you can also search for and play iPod music using Song By Voice.

Models with ODM

Bluetooth® Audio

Play streaming or stored audio from your compatible phone when it is paired to *Bluetooth HandsFreeLink*. Visit www.acura.com/handsfreelink (U.S.) or www.handsfreelink.ca (Canada) to check phone compatibility. Standard data rates may apply.



Notes:

- Make sure the volume on your phone is properly adjusted.
- You may need to enable additional settings on your phone for playback.
- The resume/pause function and remote audio controls are not supported on all phones.

Applicable laws may prohibit the operation of handheld electronic devices while operating a vehicle. Only launch streaming audio on your phone when safe to do so.