

## Voice Command

### *Using the Voice Command System*


To reduce driver distraction, use voice commands for hands-free calling, navigation/compass, audio, AcuraLink, and climate control functions. A full list of these commands is in the navigation system manual.

**HFL Talk button:** Give HFL commands or answer incoming calls.

**NAVI Talk button:** Give navigation, audio, and climate control commands.

**NAVI Back button:** Cancel a command or return to the previous screen.

**HFL Back button:** End a call, go back to the previous command, or cancel an operation.




### Voice Command Tips:

- Press and release the Talk button, wait for a beep, then give a command.
- To hear a list of available commands at any time, say "Hands free help" after you press and release the Talk button.
- Speak in a clear, natural voice.
- Reduce all background noise.
- Adjust the dashboard and side vents away from the microphone in the ceiling.
- Close the windows.

# Bluetooth® HandsFreeLink®

## Pairing Your Phone


Press and release the HFL Talk button before you give a command.



For more information or troubleshooting, call HFL consumer support at (888) 528-7876, visit [www.acura.com/handsfreelink](http://www.acura.com/handsfreelink), or see your owner's manual for details.

## Making a Call

1. **Press** the HFL Talk button.



2. **Say** "Call" and the desired phone number.



3. **Press** the HFL Talk button and **say** "Call" or "Dial" to continue.



4. The call is connected and heard through the speakers.




## Receiving a Call

1. A notification is heard, and "INCOMING CALL" and the phone number appear on the MID.



2. **Press** the HFL Talk button to accept the call.



3. **Press** the HFL Back button to decline or end the call.



## Navigation (if equipped)

### Entering a Destination Using Voice Control

Press and release the NAVI Talk button before you give a command.

**1** Say "Display menu."

**2** Say "Address."

**3** Say "City" (or "Change state" if necessary).

**4** Say the name of the city you want, or say "Current city" to select the city currently shown.


**5** A list of city names appears. Say the number listed next to the city you want to select.

**6** Say the street name. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).

**7** A list of street names appears. Say the number listed next to the street you want to select.

**8** Say the entire street address number. For example, "1-2-5-0."

**9** The system calculates the route and displays the "Calculate route to" screen. Say "OK" to set the route.



**Note:** Entering a destination can also be done manually with the Interface Dial from the Menu screen.

## Entering a Destination Using the “Find Nearest” Command

Try these simple steps to find a nearby point of interest, such as a gas station, movie theater, restaurant, etc.

Press and release the NAVI Talk button before you give a command.


1. Say “Find nearest ATM.”




2. A list of the nearest ATMs in your area is displayed by shortest distance to destination.



3. Say the number you want to select.



4. The system calculates the route and displays the “Calculate route to” screen. Say “OK” to set the route.



## Commonly Used Voice Commands

Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

Press and release the NAVI Talk button before you give a command.


### Looking for Restaurants in Your Location

Say a command like “Display Chinese restaurants” to see restaurant icons appear on the map.



### Making Audio Selections

Say a command like “Radio 97.1 FM” or “CD play track 5” to select that station or song.




### Adjusting Vehicle's Climate Setting

Say a command like “Air conditioner on” and “Fan speed 4” to achieve a comfortable climate setting.



### Getting Estimated Distance to Destination

After a destination is entered, say “How far to destination?” to hear the remaining distance.



## Commonly Used Voice Commands (continued)

Press and release the NAVI Talk button before you give a command.

### General Commands

(Accepted on most screens)



- Display map
- Display menu
- Setup
- Information
- Display audio screen
- What time is it?

### Find Place Commands

(Accepted on map screen)



- Find nearest:
  - ATM
  - gas station
  - Mexican restaurant
  - post office
  - bank
  - Acura dealer
  - airport
  - hospital

### Navigation Commands

(Accepted on map screen after a destination is entered)



- How long/far to the destination?
- Display destination
- Display entire route

### Display Commands

(Accepted on map screen)



- Display (or hide):
  - ATM
  - gas station
  - Mexican restaurant
  - post office
  - Display north up/heading up
  - Zoom in/out
  - Go home
  - Display current location

## Commonly Used Voice Commands (continued)

Press and release the NAVI Talk button before you give a command.

### Audio Commands

(Accepted on most screens)



- Radio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- XM channel #
- XM preset 1/2/3/4/5/6
- CD play
- CD play track/disc #
- CD skip forward/back
- Auxiliary (AUX) play

### Setup Commands

(Accepted on the setup screen)



- Brightness up/down
- Volume up/down/min/max/off
- Interface dial feedback on/off
- Guidance prompts min/max/normal

### Climate Control Commands


(Accepted on most screens)



- Air conditioner on/off
- Rear defrost on/off
- Climate control recirculate/fresh air
- Fan speed up/down
- Temperature # degrees (# = 57–87)
- Temperature max hot/cold

### Help Commands

(Accepted on most screens)



- Help (list of available commands for current screen)
- Voice command help (list of all available navigation, audio, and climate control commands)




## AcuraLink Real-Time Traffic™\*

Provides continuously updated info, including traffic speed, incidents, and construction in major metro areas.

Press and release the NAVI Talk button before you give a command.

### Displaying Traffic Information

Say "Display traffic" to view highway flow data.




Traffic Flow Data

- Heavy traffic
- Moderate traffic
- Free-flow traffic

**NOTE:** Traffic flow and incident icons can only be displayed on map scales of 5 miles (8 km) or less.

### Displaying Traffic Incidents

Say "Display traffic incidents" to view a list of incidents in your area or on your specific route, which are listed by distance from your current position.



### Incident Icons

- Accident
- Construction
- Congestion
- Road Closed

\* Subscription-based service through Sirius XM Radio® (free 90-day trial upon vehicle purchase)

\*\* You can also display this information manually using the Interface Dial from the Map screen.


## AcuraLink Real-Time Weather™\*

Provides current weather conditions, warnings, and forecasts in major metro areas.

### Displaying Weather Icons

Press and release the NAVI Talk button before you give a command.

Say "Display weather"\*\*\* to view weather icons for each city. These are available on all map scales.




### Checking Weather Forecasts and Warnings

1. Say "Display information."




2. Say "Weather information."



To view the weather forecast: say "Current position" or "City vicinity."

To view weather warnings: say "Warning list sorted by distance."



\* Subscription-based service through Sirius XM Radio® (free 90-day trial upon vehicle purchase)

\*\* You can also display this information manually using the Interface Dial from the Map screen.

Voice Command/  
HFL/Navigation