

NAVIGATION






Real-time navigation system uses GPS and a map database to show your current location and help guide you to a desired destination.

Entering a Destination Address Using Voice Commands

Set a destination using a street address. For other destination options, see your Navigation Manual.

Press and release the Talk button before you give a command.

1. Say "Display menu." Say "Address."
2. Say "Street," then say the street name on the next screen. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).
3. A list of street names appears. Say the number next to the street you want.
4. Say the entire street address number. For example, "1-2-3-4." If necessary, say "OK" to proceed.
5. If the street address is in more than one city, a list of city names appears. Say the number next to the city you want.
6. The system displays the "Calculate route to" screen. Say "OK" to set the route.






Using the Find Nearest Command

Find a nearby point of interest, such as a gas station, movie theater, restaurant, etc.

Press and release the Talk button before you give a command.


1. From the map screen, say "Find nearest ATM."
2. A list of the nearest ATMs in your area is displayed by shortest distance to destination.
3. Say the number next to the destination you want.
4. The system calculates and displays the route.



Map Screen Legend



- Calculated Route
- Direction of destination
- Distance to go
- Current vehicle location




ACURALINK REAL-TIME TRAFFIC™*

Provides continuously updated info, including traffic speed, incidents, and construction in major metro areas.

Press and release the Talk button before you give a command.

Displaying Traffic Information

Say "Display traffic" to view traffic flow and incident icons.



- Heavy traffic
- Moderate traffic
- Free-flow traffic





NOTE: Traffic flow and incident icons can only be displayed on map scales of 5 miles (8 km) or less.

- ### Incident Icons
- Incident
 - Congestion
 - Construction
 - Road closed
 - Weather

Traffic Rerouting

When a destination is set, you can create a detour to avoid traffic incidents or congestion (if Traffic Rerouting is set to ON in Setup).

1. Say "Display traffic incidents" to view a list of incidents on your route.
2. Say the number of the incident you want to avoid. When the incident appears, say "Traffic detail."
3. Say "Avoid," and the incident list returns.
4. Say "Reroute" to set the new route.



* Subscription-based service through Sirius XM Radio® (free 90-day trial upon vehicle purchase)


ACURALINK REAL-TIME WEATHER™*

Provides continuously updated weather conditions, warnings, and forecasts in major metro areas.

Press and release the Talk button before you give a command.

Displaying Weather Icons

Say "Display weather" to view weather icons for each city.



- ### Weather Icons
- Clear
 - Partly Cloudy
 - Cloudy
 - Fog
 - Rain
 - Snow


NOTE: Weather icons are available on all map scales.

Displaying Weather Information

Say "Information," then "Weather information" for the following options:


Weather Forecast

Say "Weather forecast" to view a 1-day or 3-day forecast of your current position or city vicinity.




Radar Image Map

Say "Radar map" to view color-coded rain or snow systems.




Weather Warning List

Say "Warning list sorted by distance" to view a list of all U.S. weather warnings by distance.



Weather Warning Map

Say "Warning map" to view color-coded severe weather systems.



* Subscription-based service through Sirius XM Radio® (free 90-day trial upon vehicle purchase)