# KEYLESS ACCESS SYSTEM (Tech models)

This system allows you to operate certain functions of your vehicle by simply having the remote within operating range.

## Unlocking the Doors



**Grab** either one of the front door handles.

## Locking the Doors



**Press** the door lock button on either front door handle.

## Opening the Trunk

**Press** the trunk release switch under the spoiler.

## Engine Start/Stop Button

### Accessory Mode

Use audio, power sockets, power windows, etc. without turning the engine on



**Press** the ENGINE START/STOP button once.

### Starting the engine



**Press and hold** the brake pedal* then **press** the ENGINE START/STOP button.

* For manual transmissions, **press and hold** the clutch.

### Turning the engine off



**Shift** to Park* then **press** the ENGINE START/STOP button.

* For manual transmissions, **apply** the emergency brake.

# KEYLESS MEMORY SETTINGS

Each remote (labeled 1 or 2 on the back) activates its own set of programmable audio, climate, driving position memory, and customized settings (MID)*.

## Checking the Remote

1. Verify that you are using the correct remote by turning the vehicle on.




2. Check the MID:
   - If you have the correct remote, the driver ID that appears first on the MID will match the ID number on the back of your remote. **Go** to step 3.

   - If the numbers do not match, follow these simple instructions:
     - **Turn** the vehicle off.




     - **Press** the unlock button on your remote.



     - **Turn** the vehicle on again, and **check** the MID. The driver ID that appears first on the MID should now match the number on the back of your remote.

3. Once you have the correct remote, you can begin to program your Keyless Memory settings.

Tech model shown