VOICE COMMAND INDEX

Learn about all available voice commands to help you operate the certain features. Press the Talk button before you say a command. Available on vehicles with navigation.

To view a list of available commands in the vehicle, press the INFO button and use the interface dial to select Voice Info. Select a category to hear the commands read aloud.

■ Global Commands

The system accepts these commands on most screens.

- Voice help
- Display voice portal
- Display phone (or PHONE button)
- Display audio (or AUDIO button)
- Display information (or INFO button)
- Display menu (or MENU button)
- Display setting (or SETTINGS button)
- Display map
- Display navigation
- Back (returns to previous screen)
- Cancel
- What is today's date?
- What time is it?
- Messages
- Trip computer
- Display clock

■ Navigation Commands

The system accepts these commands on the map/guidance screen.

Route Commands

The system accepts these commands when a route is set.

- How long to the destination?
- How far to the destination?
- Display destination map
- Display entire route
- Cancel route
- Go home

Map Display Commands

- Display/Hide (specify icon type):
  ATM
  gas station
  restaurant
  post office
  grocery store
  lodging (hotel, motel)
  parking lot
  school
  hospital
  traffic
  traffic speeds
  traffic icons
  traffic incidents
- Display current location
- Display north up
- Display heading up
- Display 3D map
- Display zoom in
- Display zoom out

■ Navigation Commands (continued)

Find Place Commands

- Find nearest (specify place):

Fuel and auto	Performing arts
Acura dealer	Sports complex
Gas station	Tourist attraction
Auto parts & electronics	Restaurant
Auto repair & maintenance	American restaurant
Car wash & detailing	Californian restaurant
Motorcycle dealer	Chinese restaurant
Other car dealer	Coffee shop
Roadside assistance	Continental restaurant
Banking center	Fast food
ATM and bank	French restaurant
ATM	German restaurant
Bank	Greek restaurant
Check cashing	Indian restaurant
Currency exchange	Italian restaurant
Community	Japanese restaurant
Business	Korean restaurant
City hall	Mexican restaurant
Civic center	Pizza
Convention center	Seafood restaurant
Court house	Thai restaurant
Higher education	Vegetarian restaurant
Library	Vietnamese restaurant
Post office	Other restaurant
School	Shopping
Emergency room	Shopping area
Hospital	Accessory store
Police station	Book store
Veterinarian	Clothing store
Lodging	Grocery store
Bed & breakfast	Home improvement store
Hotel	Mall
Resort	Office supply store
Recreation	Pharmacy
Amusement park	Pet food store
Golf course	Sewing store
Historical monument	Shoe store
Marina	Sporting goods store
Movie theater	Toy store
Museum	Travel center
Park	Airport

■ Navigation Commands (continued)

Find Place Commands (continued)

• Find nearest (specify place):

Automobile club	Parking lot
Bus station	Rental car agency
Camping	Rest area
Commuter rail station	Ski area
Ferry terminal	Tourist information center
Named place	Train station
Park & ride	Travel agency
Parking garage	Truck stop

■ Climate Control Commands

The system accepts these commands on most screens.

• Climate control automatic*
• Climate control on*
• Climate control off*
• Air conditioner on*
• Air conditioner off*
• Climate control defrost on*
• Climate control defrost off*
• Rear defrost on*
• Rear defrost off*
• Climate control fresh air
• Climate control recirculate
• Climate control sync on*
• Climate control sync off*
• Climate control vent
• Climate control bi-level
• Climate control floor
• Climate control floor and defrost
• Fan speed up
• Fan speed down
• Fan speed # (#: 1 to 7)

• Fan automatic
• Temperature # degrees (#: 57 to 87°F / 15 to 29 °C)
• Driver temperature # degrees (#: 57 to 87°F / 15 to 29 °C)
• Passenger temperature # degrees (#: 57 to 87°F / 15 to 29 °C)
• Temperature up
• Temperature down
• Driver temperature up
• Driver temperature down
• Passenger temperature up
• Passenger temperature down
• Temperature max heat
• Temperature max cool
• Driver temperature max heat
• Driver temperature max cool
• Passenger temperature max heat
• Passenger temperature max cool

*These commands toggle the function on and off, so the
command may not match your intended action.*

■ Audio Commands

The system accepts these commands on most screens. Audio volume levels cannot be controlled using voice commands.

FM/AM Radio Commands

- Audio on*
- Audio off*
- Radio on*
- Radio off*
- Radio select FM
- Radio select AM
- Radio tune to # FM (#: frequency, e.g., 95.5)
- Radio tune to # AM (#: frequency, e.g., 1020)
- Radio seek up
- Radio seek down
- Radio next station
- Radio preset # (#: 1 to 12)
- Radio FM preset # (#: 1 to 12)
- Radio AM preset # (#: 1 to 6)
- Radio FM tag song**
- Radio AM tag song**
- Radio scan*

SiriusXM Radio Commands

- Radio select SiriusXM
- SiriusXM channel # (#: 0 to 999)
- SiriusXM channel up
- SiriusXM channel down
- SiriusXM category up
- SiriusXM category down
- SiriusXM preset # (#: 1 to 6)
- SiriusXM scan*
- SiriusXM category mode
- SiriusXM channel mode
- SiriusXM skip forward
- SiriusXM skip back
- SiriusXM scan songs
- SiriusXM play
- SiriusXM pause
- SiriusXM go to live
- SiriusXM tag song**

Compact Disc (CD) Commands

- Disc play
- Disc play track # (#: 1 to 30)
- Disc skip forward
- Disc skip back
- Disc track random*
- Disc track repeat*
- Disc track scan*
- Disc folder up
- Disc folder down
- Disc folder random*
- Disc folder repeat*
- Disc folder scan*
- Disc normal play

Hard Disc Drive (HDD) Commands

- Hard disc drive play
- Hard disc drive play track # (#: 1-30)
- Hard disc drive skip forward
- Hard disc drive skip back
- Hard disc drive album up
- Hard disc drive album down
- Hard disc drive track up
- Hard disc drive track down
- Hard disc drive playlist up
- Hard disc drive playlist down
- Hard disc drive track random*
- Hard disc drive track repeat*
- Hard disc drive track scan*
- Hard disc drive normal play
- What am I listening to?
- Who am I listening to?
- Who is this?
- What's playing?
- Who's playing?
- What album is this?

These commands toggle the function on and off, so the command may not match your intended action.

**if equipped*

■ Audio Commands (continued)

USB Commands

- USB play
- USB play track # (#: 1 to 30)
- USB skip forward
- USB skip back
- USB track random*
- USB track repeat*
- USB track scan*
- USB folder up
- USB folder down
- USB folder random*
- USB folder repeat*
- USB folder scan*
- USB normal play

iPod® Commands

- iPod play
- iPod pause
- iPod play track # (#: 1-30)
- iPod skip forward
- iPod skip back
- iPod track shuffle*
- iPod album shuffle*
- iPod track repeat*
- iPod normal play
- What am I listening to?
- Who am I listening to?
- Who is this?
- What's playing?
- Who's playing?
- What album is this?

Pandora® Commands (U.S. only)

- Pandora play
- Pandora skip forward
- Pandora station up
- Pandora station down
- Pandora pause
- Pandora resume
- Pandora thumbs up
- Pandora thumbs down

Aha™ Radio Commands

- Aha radio play
- Aha radio skip forward
- Aha radio skip back
- Aha radio station up
- Aha radio station down
- Aha radio pause
- Aha radio resume
- Aha radio like
- Aha radio dislike

Bluetooth® Audio Commands

- *Bluetooth* audio play
- *Bluetooth* audio skip forward
- *Bluetooth* audio skip back
- *Bluetooth* audio pause
- *Bluetooth* audio resume
- *Bluetooth* audio group up
- *Bluetooth* audio group down

  Commands may not work on some phones or devices.

AUX Commands

- Auxiliary play

Song By Voice™ Commands

These commands can be used for iPod and HDD operation.

- Music search
- What am I listening to?
- Who am I listening to?
- Who is this?
- What's playing?
- Who's playing?
- What album is this?

* These commands toggle the function on and off, so the command may not match your intended action.

■ Phone Commands

The system accepts these commands on most screens.

- Call by number
- Call by name
- Call (phone number)
- Call (contact name)

■ On-screen Commands

The system accepts these commands on any screen where applicable. All available on-screen voice commands are highlighted in yellow when you press the Talk button.

- Next (or Down)
- Previous (or Up)
- Return
- OK (excluding Startup Confirmation screen)
- Delete