

BLUETOOTH® HANDSFREELINK®

Make and receive phone calls through your vehicle's audio system. Visit www.acura.com/handsfreelink to check if your phone is Bluetooth-compatible.

To prevent driver distraction, certain functions may be inoperable or grayed out while the vehicle is moving. Stop or pull over to perform the function.


Using HFL

Pick-Up button: Answer an incoming call or go directly to the Phone screen.

Hang-Up button: End a call or decline an incoming call.

Talk button: Make a call using a stored voice tag.

Back button: Press to cancel an operation or return to the previous screen.



Use these three buttons to navigate through the HFL menus.

PHONE button: Go directly to the Phone screen.

Back button: Press to cancel an operation or return to the previous screen.



Audio selector knob:


Rotate to scroll through selections and press to make a selection.

Pairing Your Phone


Use this pairing method if no phone has ever been paired to the system. You can only pair your phone when the vehicle is stopped.

Use the audio selector knob to make and enter selections.


1. **Press** the Pick-Up button to access the Phone screen. A prompt appears. **Select** Yes.



2. Make sure your phone is in discovery mode. **Select** OK.




3. HFL searches for your phone. **Select** it when it appears on the list.




If your phone does not appear:

Select Phone Not Found, and **search** for HandsFreeLink from your phone. **Connect** to HFL.



4. HFL gives you a four-digit code. **Enter** it on your phone when prompted. The phone is now paired.



Use this pairing method when a phone has already been paired to the system, or when you want to pair an additional phone.


Use the audio selector knob to make and enter selections.

1. **Press** the Pick-Up button to access the Phone screen.




If a prompt appears asking to connect to a phone, **select** No.


2. **Select** Phone setup.



3. **Select** Connection.




4. **Select** Add a New Phone.




5. **Select** an empty location for the phone.



6. Make sure your phone is in discovery mode, and **select** OK.




7. HFL searches for your phone. **Select** your phone when it appears on the list.




If your phone does not appear:

Select Phone Not Found and **search** for HandsFreeLink from your phone. **Connect** to HFL.



8. HFL gives you a four-digit code. **Enter** it on your phone when prompted. The phone is now paired.




Dialing a Number

Enter a 10-digit phone number to call. This feature is inoperable when the vehicle is moving.

Use the audio selector knob to make and enter selections.


1. **Press** the Pick-Up button to go to the Phone screen.




2. **Select** Dial.



3. **Enter** the phone number. **Select** the green Dial icon or **press** the Pick-Up button to call.




4. The call is connected and heard through the vehicle speakers.



Receiving a Call

When you receive an incoming call, you hear a notification and see the following pop-up message:



Press the Pick-Up button to accept the call.



Press the Hang-Up button to end or decline the call.




Using the Phonebook

When your phone is paired, its entire phonebook is automatically imported to the system. This feature is inoperable when the vehicle is moving.

Use the audio selector knob to make and enter selections.


1. **Press** the Pick-Up button to go to the Phone screen.




2. **Select** Phonebook.



3. **Scroll** through the list to find the name and number you want to call, and **select** it.




4. The call is connected and heard through the vehicle speakers.




Using Speed Dial

When a speed dial entry is stored with a voice tag, you can make a call using voice commands at any time. See your Owner's Manual for more information.


1. **Press** the Talk button. The system asks which name you want to call.



3. The call is connected and heard through the vehicle speakers.



2. **Say** the stored voice tag name.



To reduce the potential for driver distraction, certain functions may be inoperable or grayed out while the vehicle is moving. You may have to use voice commands, stop or pull over to perform the function.

The chart below shows a list of some operations that are restricted while the vehicle is moving.

Driver Distraction

Function	Restriction Level While Driving
HFL System (Without Navigation)	
10-key dial	Restricted
Phonebook	Restricted
Speed dial	Not restricted
Speed dial setup	Restricted
Call history	Not restricted
Call history scroll	Not restricted.
Redial	Not restricted
Connect to a new phone	Restricted
Connect to a previously paired phone	Not restricted
Manual dial tones	Restricted
Read text	Restricted
Reply to text	Not restricted
HFL System (With Navigation)	
10-key dial	Voice command only
Phonebook	Voice command only. Limited to three screens
Speed dial	Not restricted
Speed dial setup	Restricted
Call history	Not restricted
Call history scroll	Voice command only. Limited to three screens
Redial	Not restricted
Connect to new phone	Restricted