

NAVIGATION*

Learn how to enter a destination and operate the navigation system.

Basic Navigation Operation

A real-time navigation system uses GPS and a map database to show your current location and help guide you to a desired destination. You can operate the system using voice commands or the system controls.


To reduce the potential for driver distraction, certain manual functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.

■ Steering Wheel Controls

Use the steering wheel controls to give voice commands.

Hang-Up/Back button: Press to cancel a command or operation.

Talk button: Press to say navigation commands from the Voice Portal screen.



■ Voice Command Tips

When using the Talk button, wait for the beep before saying a command. The system recognizes only the commands in the Voice Command Index

- To bypass the system prompts, simply press the Talk button again to say your command.
- Speak in a clear, natural voice.
- Reduce all background noise.
- Adjust the dashboard and side vents away from the microphone in the ceiling. Fan speed may be temporarily reduced during voice recognition operation.
- Close the windows and moonroof.




WARNING

Using the navigation system while driving can take your attention away from the road, causing a crash in which you could be seriously injured or killed.

Only operate system controls when the conditions permit you to safely do so.

■ Navigation Display and Controls


Use the controls to enter information and make selections. Some manual functions are inoperable while driving.



■ System Guidance Volume

Adjust the navigation system guidance volume. This does not affect audio or *Bluetooth*® HandsFreeLink® volume, which is controlled by the volume knob. Use the interface dial to make and enter selections.


1. Press **SETTINGS**.
2. Select **System Settings**.
3. Select **Voice Reco.**
4. Adjust the volume to your preferred level.
5. Press **BACK** to exit the menu.



■ Voice Prompt

Turn the voice prompt feature on or off. Use the interface dial to make and enter selections.

1. Press **SETTINGS**.
2. Select **System Settings**.
3. Select **Voice Prompt**.
4. Select **Off** or **On**.
On: Provides voice prompts.
Off: Voice prompts are disabled.




Entering a Destination

Use several methods to enter a destination.

■ Home Address

Store your home address in the system so you can easily route to it. Use the interface dial to make and enter selections.

1. Press the SETTINGS button.
2. Select Navigation Settings.
3. Select Edit Go Home.
4. Select Address and enter it.
5. Select Save.




When your home address is stored, you can press the Talk button and say *“Navigation”* and then *“Go home”* at any time. You can also press the MENU button and select Go Home.

■ Street Address

Enter a street address using voice commands (U.S. models only). Press the Talk button to enter the Voice Portal screen.

You can also enter the address manually when the vehicle is stopped. While on the map screen, press the MENU button and use the interface dial to select Address. Follow the prompts.


1. From the Voice Portal screen, say *“Navigation”* and then *“Address.”*
2. The system prompts you to say the entire address. For example, say *“1-2-3-4 Main Street, Los Angeles, California.”*
3. The system interprets the address by state, city, street, and address number. If necessary, you may have to clarify similar matches.
4. Say *“Set as destination”* to set the route.



■ Place Name

Enter a place name stored in the navigation database using voice commands (U.S. models only). Press the Talk button to enter the Voice Portal screen.

1. From the Voice Portal, say *“Navigation”* and then *“Place name.”*
2. Say a category. For example, *“ATM/Bank.”*
3. Say the name of the point of interest. For example, *“ABC Bank.”*
4. The system interprets the name. If necessary, you may have to clarify similar matches. If there is more than one point of interest with the name, a list of matches appears in order of closest distance. Use the interface dial to select an entry.
5. Use the interface dial to select *“Set as destination”* to set the route.




You can also enter the place name manually when the vehicle is stopped. While on the map screen, press the MENU button and use the interface dial to select Place Name. Enter the name and follow the prompts.

■ Find Nearest Place

Enter a destination by category and distance using voice commands. Press the Talk button to enter the Voice Portal screen.

1. Say *“Navigation”* and then *“Find nearest (POI category)”* and a place. For example, *“Find nearest ATM.”*
2. A list of the nearest places in your area is displayed by shortest distance to destination.
3. Use the interface dial to select an entry.
4. Use the interface dial to select *“Set as destination”* to set the route.



Routing

After a destination is set, you can alter or cancel your route.

■ Map Legend

During route guidance


Estimated
time to
destination

Distance to
destination



Next
guidance
point

Calculated
route




Turn-by-Turn Directions

Shows a more detailed view of the next maneuver on the multi-information display. Use the right selector wheel on the steering wheel to bypass the display.

Distance
to next
maneuver

Current route



Upcoming
maneuver

■ Taking a Detour


You can calculate a detour route manually if you encounter a road closure or other obstacle. Use the interface dial to make and enter selections.

1. When en route, press the MENU button.
2. Select Detour. The system attempts to calculate a new route by avoiding the next 5 miles (8 km) while on a freeway or 1 mile (1 km) while on a surface street.

■ AcuraLink Real-Time Traffic™*

View traffic flow, incidents, and construction in major metro areas. You can also route around congestion or incidents when you have a destination set. Use the interface dial to make and enter selections. **Available in the U.S. only.**

1. From the map screen, press the interface dial. Select Map/Route. Select Traffic Incidents.
2. A list of incidents on your route appears. Select the incident you want to avoid.
3. Select Avoid. Repeat as necessary to select other incidents.
4. Select Recalculate Route.



**Requires AcuraLink subscription.*

■ Canceling Your Route

You can cancel your route at any time.

1. When en route, press the MENU button.
2. Select Cancel Route. The route is cleared and the map screen returns.