


Customized Features

When you customize settings, make sure that the vehicle is at a complete stop and shift to Park (P).

Using the Information Screen



■ To Change a Setting

Using the Information Screen

1. Press the **SETTINGS** button.
2. Rotate the **interface dial** to view categories.
3. Press the **interface dial** to select.

Setting the Clock

On vehicles with navigation, the time is automatically set using GPS signals. To manually adjust the clock, use the following steps:

Using the Information Screen

1. Press the **SETTINGS** button.
2. Rotate interface dial to select **Clock Settings**, then press the interface dial.
3. Rotate the interface dial to select **Clock Adjustment**, then press the interface dial.
4. Rotate the interface dial to change the hours, then move interface dial to the right to select the minutes.
5. Rotate the interface dial to change the minutes, then press the dial to set.

