


Note function (on navigation screen)

You can store a sound content of the selected XM Satellite Radio with a category, name and title information.

To activate this function, press and hold XM button for about 2 seconds. Up to 30 sound files can be stored.



To replay the stored file;
Press the AUDIO button.
Push down the selector.
Turn the knob to select
NOTE, then press ENTER.

Turn the knob to select a
file, then press ENTER.