


AcuraLink Real-Time Traffic™ * (Technology Package)

Provides continuously updated info, including traffic speed and flow, incidents, and construction in major metro areas.

Press and release the NAVI Talk button before you give a command.

Displaying Traffic Information

Say "Display traffic" ** to view highway flow data.




Traffic Flow Data

- Heavy traffic
- Moderate traffic
- Free-flow traffic

NOTE: Traffic flow and incident icons can only be displayed on map scales of 5 miles (8 km) or less.

Displaying Traffic Incidents

Say "Display traffic incidents" ** to view a list of incidents in your area or on your specific route, which are listed by distance from your current position.



Incident Icons

- Accident
- Construction
- Congestion
- Road Closed

* Subscription-based service through Sirius XM Radio® (free 90-day trial upon vehicle purchase)

** You can also display this information manually using the Interface Dial from the Map screen.