

Bluetooth® Audio


Plays audio files from your compatible phone through your vehicle's audio system.

Playing Bluetooth Audio Files

1. Make sure your phone is on and paired to HandsFreeLink (See [HandsFreeLink](#)).
2. Press the AUDIO button and press the DISC/AUX button repeatedly until "Bluetooth Audio" appears.



3. Press "play" on your phone; sound is redirected to the audio system.



Skipping Bluetooth Audio Files

There are three ways to skip through audio files:

Press (▶▶) or (◀◀) on the audio control panel.




Move the selector knob to the left or right.




Skipping Bluetooth Audio Files (continued)

Press (+) or (-) on the remote audio controls.



Audio Options

1. **Press** the AUDIO button, then **press** the selector knob down to display the Audio Menu.



2. **Turn** the selector knob to select either RESUME/PAUSE or SOUND, then **press** ENTER.



Playing an iPod® or USB Flash Memory Device

Some CD player controls also operate an iPod or USB flash memory device.

Connecting and Beginning Play

1. **Open** the center console, and **pull out** the USB adapter cable.



2. **Connect** the USB connector to your iPod dock connector or flash drive.



3. **Press** the DISC/AUX button to begin playing.




The Note Function (models with navigation)

Use the Note function to store up to 30 ten-second recordings of songs and song information from XM Radio.

1. To record a song sample, **press and hold** the XM button for about 2 seconds.



2. To replay stored information, **press** the AUDIO button, and then **push** the selector knob down.



3. Turn the selector knob to select NOTE, then **press** ENTER.



4. Turn the selector knob to select a sound file, then **press** ENTER. The selected song plays.

