



Traffic Display

Incident Icons

- Accident/Incident 
- Construction 
- Weather 
- Road Closed 

Incident icon update details:


- Typically M-F 5:00 AM –7:00 PM (varies by metropolitan region)

Viewing Incident Details:




To view incident details, use the interface dial to position the cursor (round red circle below) over an incident icon and push in.

Hearing Incident Details:

Push on the interface dial twice.



Traffic Flow Data (where available)

-  Heavy traffic: 0 – 27 mph (approx.)
-  Moderate traffic: 27 – 52 mph (approx.)
-  Free flow traffic: 52+ mph (approx.)

Map Scale

Traffic flow and incident icons are displayed on the 5 mile (8 km) or less map scale.

Note: If your highlighted route takes you on roads that have traffic data, the route line is used to display the traffic instead of a colored line on the side of the road. Your highlighted route may change from the normal "blue" to orange or red depending on the traffic conditions at that time.

Traffic Flow Data Update Details:

- Available 24 hrs a day, 7 days a week (not available in all metro traffic coverage areas)

Real-Time Traffic Display: The navigation screen can display up-to-the-minute traffic information when available including flow (traffic speed), accidents, and construction on freeways in major metro areas. The display of traffic flow and incidents on your map screen is optional and can be turned On/Off by selecting the "Traffic" icon on the Icon bar (see the navigation Owners Manual for details).

Viewing Flow Data: Traffic flow data is displayed as colored bands on either side of the highway (see the map diagram). The amount of flow data varies considerably from one city to another. You can only view traffic information in the city where you are located.

Note:

The displayed traffic flow may disagree with the information from other audio or internet based traffic displays.

Viewing Incident Reports: Incident reports appear as small diamond-shaped icons (see traffic map screen for examples). There are three ways to view traffic incidents from the map screen:

1. Using voice control, say "Display traffic incidents." Incidents (if any) are listed, with the closest shown first. When selected, a pop-up appears providing details of the incident.
2. Push in the interface dial and select the "Traffic Incidents" button from the Map Menu.
3. Use the interface dial to position the cursor (the round red circle) over the desired incident icon. Push in the interface dial to view the incident details, and push it a second time to hear the message.

Notes:

- *Incident reports may be displayed on roads that have no flow data available.*
- *Freeway incident reports can lag behind the actual incident, or remain displayed after an incident has cleared. This is normal.*
- *The displayed incidents may disagree with the information from other audio or internet based traffic information.*

Traffic Coverage: For the latest traffic coverage details for covered metropolitan areas, check www.acura.com/realtimetraffic for TSX.

*** Check the owner's manual for additional information and instructions.**