

## ACURALINK REAL-TIME WEATHER™\* (if equipped)

Provides continuously updated weather conditions, warnings, and forecasts in major metro areas.

Press and release the Talk button before you give a command.

### Displaying Weather Icons

Say "Display weather" to view weather icons for each city.



**NOTE:** Weather icons are available on all map scales.

#### Weather Icons:



Clear



Fog



Partly  
Cloudy



Rain



Cloudy




Snow

### Displaying Weather Information

Say "Information," then "Weather information" for the following options:

#### Weather Forecast

Say "Weather forecast" to view a 1-day or 3-day forecast of your current position or city vicinity.



#### Radar Image Map

Say "Radar map" to view color-coded rain or snow systems.




#### Weather Warning List

Say "Warning list sorted by distance" to view a list of all U.S. weather warnings by distance.



#### Weather Warning Map

Say "Warning map" to view color-coded severe weather systems.



\* Subscription-based service through Sirius XM Radio® (free 90-day trial upon vehicle purchase)

\*\* You can also display this information manually using the Interface Dial from the Map menu.