

KEYLESS ACCESS SYSTEM (Tech/Advance)

Operate certain functions of your vehicle by simply having the remote within operating range.


Unlocking the Doors




Grab either one of the front door handles.



Locking the Doors



Press the door lock button on either front door handle.



Opening the Trunk



Press the trunk release button under the spoiler.



Engine Start/Stop Button

Accessory Mode

Use audio, power sockets, etc., without turning the engine on.



Press the ENGINE START/STOP button once (without pressing the brake pedal).



Starting the engine



Press and hold the brake pedal*, then **press** the ENGINE START/STOP button.



* For manual transmissions, **press and hold** the clutch.

Turning the engine off



Shift to Park*, then **press** the ENGINE START/STOP button.



* For manual transmissions, **apply** the emergency brake.