

ACURALINK REAL-TIME TRAFFIC™* (if equipped)

Provides continuously updated info, including traffic speed, incidents, and construction in major metro areas.

Press and release the Talk button before you say a command.

Displaying Traffic Information

Say "Display traffic" to view traffic flow and incident icons.



Heavy traffic

Moderate traffic


Free-flow traffic

Note: Traffic flow and incident icons can only be displayed on map scales of 5 miles (8 km) or less.

Incident Icons



Incident



Road closed



Congestion



Weather




Construction


Traffic Rerouting™

When a destination is already set, you can create a detour to avoid traffic incidents or congestion (if Traffic Rerouting is set to ON in Setup).


1. Say "Display traffic list" to view a list of incidents on your route.




2. Say the number of the incident you want to avoid. When the incident appears, say "Traffic detail."



3. Say "Avoid," and the incident list returns.



4. Say "Reroute" to set the new route.



* Subscription-based service through Sirius XM Radio® (free 90-day trial upon vehicle purchase)