BASIC AUDIO OPERATION

Operate basic controls of your audio system using multiple and convenient methods.

Steering Wheel Controls

When using steering wheel controls for audio operation, you can view the information in the MID.

Left selector wheel: Roll up or down to adjust volume, or push to mute. Move to the left or right to skip back or forward in stations or tracks.

SOURCE button: Change the audio source.

ODMD Controls

Select various controls depending on the audio source being played.

USB Connection

Slide back the center console door to connect a USB flash drive or iPhone/iPod dock connector to the USB port.

HARD DISC DRIVE (HDD) AUDIO

Record CDs onto your vehicle's hard disc drive for future playback. Songs are automatically recorded once a CD is inserted into the disc slot. *Available with Technology and Advance Packages.*

Playing HDD Audio

Select the HDD icon from Audio Source.

1. Select Audio Source and select the HDD icon. The last recorded album begins playing.
2. Use the ODMD or steering wheel controls to change tracks.

Searching for Music

Use the interface dial to make and enter selections.

1. Press AUDIO.
2. Press MENU.
3. Select Music Search.
4. Select one of the categories.
5. Select a track and press ENTER to begin playing.

SONG BY VOICE™

Play songs from your iPod and HDD from most screens by using simple voice commands. *Available with Technology and Advance Packages.*

Using the "Play" Command

Press and release the Talk button to say a command.

1. Say "*Music search.*"
2. Say "*Play*" and a search option. For example, "*Play artist XYZ*" or "*Play song XYZ.*"
3. The system plays the first song by the artist or the specified song and returns to your original screen.

Using the "List" Command

Press and release the Talk button to say a command.

1. Say "*Music search.*"
2. Say "*List*" and a search option. For example, "*List artist XYZ*" or "*List album XYZ.*"
3. A list of tracks by the artist or album is displayed. Say the number of your selection. For example, "*One.*"
4. The system plays the selected song and returns to your original screen.