

MULTI-INFORMATION DISPLAY (MID)

Consists of several displays that provide you with useful information.

Accessing the MID



To scroll through the different displays:

- Roll the selector wheel for the main displays.
- Press TRIP for the lower displays.




Main Displays

Vehicle Settings

Lower Displays

73°F
A 323.4 miles

Main Displays



*You can also change Vehicle Settings using the SETTINGS button on the center panel.

Lower Displays

