


Electronic Gear Selection

Select the vehicle's gear using a simple button interface.

Gear Buttons



How It Works

When the vehicle is on and ready to drive, the READY indicator appears. Press the brake pedal and select a gear.

Park (P)

Press P. A red indicator appears.




Neutral (N)

Press N. A red indicator appears.



Reverse (R)

Pull back R. A green indicator appears.



Drive (D)

Press D. A green indicator appears. Release the electric parking brake to begin driving (see page 6).



Auto Park mode

For your convenience, Park (P) is automatically selected when all of the following conditions are met:

- The vehicle is stopped.
- The driver's seatbelt is unbuckled.
- The driver's door is opened.