

# MULTI-INFORMATION DISPLAY (MID)

Consists of several displays that provide you with useful information.

## Accessing the MID



To scroll through the different displays:

- Roll the selector wheel for the main displays.
- Press TRIP for the lower displays.




Main Displays




Lower Displays

## Main Displays (models without navigation)




\*You can also change Vehicle Settings using the SETTINGS button on the center panel.

## Lower Displays



## Main Displays (models with navigation)



\*You can also change Vehicle Settings using the SETTINGS button on the center panel.

## Lower Displays

