


KEYLESS ACCESS SYSTEM

Operate certain functions of your vehicle by simply having the remote within operating range.

Unlocking the Doors



Grab either one of the front door handles.*



Locking the Doors



Press the door lock button on either front door handle.*



**For Technology and Advance Packages, all doors can be operated for this function.*


Opening the Trunk



Press the trunk release button under the trunk handle when all doors are unlocked.



Engine Start/Stop Button



Accessory or On Mode

Press ENGINE START/STOP once without pressing the brake pedal. Press it again for On mode.

Starting the Engine

Press and hold the brake pedal, then press ENGINE START/STOP.

Turning the Vehicle Off

Shift to Park, then press ENGINE START/STOP.

Note: If you press the button and the shift lever is not in Park, the vehicle goes into Accessory mode.