



## Surround View Camera\*

Four cameras assist in helping you view blind spots around the vehicle.



### ■ Displaying Front or Side Views

Press the CAMERA button when the vehicle is stationary or moving at 12 mph (20 km/h) or less. Press the button again or the interface dial to switch camera views.



### ■ Displaying the Rear View

Change the gear to Reverse (R) to display the rear view. Press CAMERA or the interface dial to switch rear views.

*The surround view camera does not eliminate all blind spots. Visually confirm safety around the vehicle with your own eyes and the mirrors. Do not rely on the camera view.*

*\*if equipped*

## ■ Changing Camera Settings

Use the interface dial to make and enter selections.

1. Press **SETTINGS**.
2. Select **Camera Settings**.
3. Select **Surround View Camera**.
4. Select one of the options:  
*Guidelines:* Turn guidelines on or off.  
*Preferences:* Choose additional settings.
5. Select an option to make your preferred changes.
6. Press **BACK** to exit the menu.



### **WARNING**

Failure to visually assess the area around the vehicle (directly or by use of the mirrors) may result in a crash causing serious injury or death.

The areas shown in the surround view camera system display are limited. The display may not show all pedestrians or other objects around your vehicle.

Do not solely rely only on the surround view camera system display to assess whether it is safe to move your vehicle.

### **WARNING**

Failure to pay proper attention to your surroundings while driving may result in a crash causing serious injury or death.

To help mitigate the chances of a collision, only look at the surround view camera system display when it is safe to do so.