


Remote Engine Start

Start your vehicle using the two-way remote transmitter from extended distances before you enter the vehicle.



Make sure the vehicle is in a safe location when using remote engine start (i.e., a well ventilated area, away from flammable materials).

■ Starting the Vehicle

Press the LOCK button, then press and hold the ENGINE HOLD button to remotely start the engine.

The vehicle starts and remains on for up to 10 minutes. To extend the time for another 10 minutes, repeat the procedure during the initial 10 minutes.

While the vehicle is on, the climate control system adjusts the interior temperature, the security system remains on, and lights and accessories remain off.

■ Turning Off the Vehicle

Press and hold the ENGINE button.

The vehicle will also turn off if it has been running for more than 10 minutes, or if any door is opened without using the remote transmitter or keyless access.

WARNING

Engine exhaust contains toxic carbon monoxide.

Breathing carbon monoxide can kill you or cause unconsciousness.


Never use the remote engine starter when the vehicle is parked in a garage or other area with limited ventilation.

Starting to Drive

The keyless access system allows simple push-button start.

■ Before Starting the Engine

Press the brake pedal. Keep your foot firmly on the brake pedal when starting the vehicle.



The engine is harder to start in cold weather and in thinner air found at altitudes above 8,000 feet (2,400 m). When starting the engine in cold weather, turn off all electrical accessories such as the lights, climate control system, and rear defogger in order to reduce battery drain.

■ Changing the Power Mode

Accessory or On Mode: Press the POWER button once without pressing the brake pedal for Accessory mode. Press it again while pressing the brake pedal for On mode.

Starting the vehicle: Press and hold the brake pedal, then press the POWER button. Keep your foot firmly on the brake pedal when starting the vehicle. The green READY indicator comes on and a message appears in the MID to let you know the vehicle is ready to drive.

Turning the vehicle off: Select Park, then press the POWER button. If you press the button and Park is not selected, the vehicle goes into Accessory mode.

