

■ Switching to Standard Cruise Control

Press and hold the Interval button for one second.

Cruise Mode Selected appears in the multi-information display for two seconds, and then the mode switches to Cruise. Press and hold the interval button again to switch back to ACC. **ACC Mode Selected** appears on the multi-information display for two seconds.

