


■ Accessory Power Socket

Located on the side of the center console. Open the socket cover to use power when the vehicle is on.




NOTICE

Do not insert an automotive type cigarette lighter element. This can overheat the power socket.

FM Radio

Play FM radio stations.



■ Selecting an HD Radio™ Subchannel


1. Select Menu.
2. Select HD Radio Subchannel.
3. Select the channel number.

Not all HD Radio stations broadcast using subchannels.

**1: Some or all of the lists may not be displayed*

SiriusXM® Radio*

Available on a subscription basis only. For more information or to subscribe, contact your dealer or visit www.siriusxm.com/subscribeNOW (U.S.) or www.sirius.ca/subscribe-now (Canada).



To learn about additional features—such as multi-channel preset, replay, or SportsFlash—see your Owner's Manual at owners.acura.com (U.S.) or myacura.ca (Canada).

Available in the U.S. and Canada, except Hawaii, Alaska, and Puerto Rico.

XM is a registered trademark of Sirius XM Radio, Inc.


** If equipped.*

**1: Some or all of the lists may not be displayed.*

Bluetooth® Audio

Play streaming or stored audio from your compatible phone through your vehicle's audio system. Connect your phone to *Bluetooth* HandsFreeLink.

Visit www.handsfreelink.com/Acura (U.S.) or call (888) 528-7876 (U.S. and Canada) to check phone compatibility. Standard data rates apply.



- Make sure the volume on your phone is properly adjusted.
- You may need to enable additional settings on your phone for playback.
- Certain audio controls are not supported on all phones.

Applicable laws may prohibit the operation of handheld electronic devices while operating a vehicle.

Launch streaming audio on your phone only when it is safe to do so.

***1: Some or all lists may not be displayed depending on the device connected.*

■ Searching for Music

Use the touchscreen to search for tracks stored on the device.

1. From the audio screen, press MENU.
2. Select Music Search.
3. Select a search category.
4. Select the track you want to play.

Music Search works with many, but not all devices.

