

AUDIO AND CONNECTIVITY


Learn how to operate the vehicle's audio system.

Basic Audio Operation


■ USB Ports

Connect a USB flash drive or other audio device, such as an iPod or iPhone. One port is in the glove box, the other in the console compartment.

1. Open the glove box and locate the USB port, on the left.
2. Install the iPod dock connector or the USB flash drive into the USB port. This port is for playing audio and device charging.



1. Open the console compartment, then open the USB port cover.
2. Install the iPod dock connector or the USB flash drive into the USB port. This port is for playing audio, device charging, and connecting to Apple CarPlay™ or Android Auto™.



iPod and iPhone are trademarks of Apple, Inc.

Applicable laws may prohibit the operation of handheld electronic devices while operating a vehicle.

■ Accessory Power Socket

Located on the side of the center console. Open the socket cover to use power when the vehicle is on.




NOTICE

Do not insert an automotive type cigarette lighter element. This can overheat the power socket.

FM Radio

Play FM radio stations.



■ Selecting an HD Radio™ Subchannel


1. Select Menu.
2. Select HD Radio Subchannel.
3. Select the channel number.

Not all HD Radio stations broadcast using subchannels.

**1: Some or all of the lists may not be displayed*

SiriusXM® Radio*

Available on a subscription basis only. For more information or to subscribe, contact your dealer or visit www.siriusxm.com/subscribeNOW (U.S.) or www.sirius.ca/subscribe-now (Canada).



To learn about additional features—such as multi-channel preset, replay, or SportsFlash—see your Owner's Manual at owners.acura.com (U.S.) or myacura.ca (Canada).

Available in the U.S. and Canada, except Hawaii, Alaska, and Puerto Rico.


XM is a registered trademark of Sirius XM Radio, Inc.

** If equipped.*

**1: Some or all of the lists may not be displayed.*

iPod®

Play and operate an iPod or iPhone through the vehicle's audio system. Connect your device to the USB port.



Applicable laws may prohibit the operation of handheld electronic devices while operating a vehicle.

**¹: Some or all of the lists may not be displayed.*

■ Searching for Music (iPod)

Use the touchscreen to search for tracks stored on the iPod. Use the touchscreen to search for tracks stored on the iPod.

1. From the audio screen, press MENU.
2. Select Music Search.
3. Select a search option.
4. Select the track you want to play.




On vehicles with navigation, you can also search for and play iPod music using Song By Voice™.

iPod is a registered trademark of Apple, Inc.

USB Flash Drive

Play and operate a USB flash drive through the vehicle's audio system. Connect your device to the USB port.



■ Searching for Music

Use the touchscreen to search for tracks stored on the USB flash drive.

1. From the audio screen, press MENU.
2. Select Music Search.
3. Select a folder.
4. Select the track you want to play.




**1: Some or all of the lists may not be displayed.*

Bluetooth® Audio

Play streaming or stored audio from your compatible phone through your vehicle's audio system. Connect your phone to *Bluetooth* HandsFreeLink.

Visit www.handsfreelink.com/Acura (U.S.) or call (888) 528-7876 (U.S. and Canada) to check phone compatibility. Standard data rates apply.



- Make sure the volume on your phone is properly adjusted.
- You may need to enable additional settings on your phone for playback.
- Certain audio controls are not supported on all phones.

Applicable laws may prohibit the operation of handheld electronic devices while operating a vehicle.

Launch streaming audio on your phone only when it is safe to do so.

***1: Some or all lists may not be displayed depending on the device connected.*

■ Searching for Music

Use the touchscreen to search for tracks stored on the device.

1. From the audio screen, press MENU.
2. Select Music Search.
3. Select a search category.
4. Select the track you want to play.

Music Search works with many, but not all devices.

