

### Homelink® Garage Opener\*1

Program your vehicle to operate up to three remote-controlled devices around your home—such as garage doors, lighting, or home security systems—using the buttons on the ceiling.



#### ■ Training a Button

Park near the system you want to program, and follow the instructions in the flowchart below.

*\*1 - If equipped*

## Training a Button

1. Position the remote transmitter you wish to link 1 to 3 inches (3 - 8 cm) from the HomeLink button you want to program.

2. Press and hold the desired HomeLink button and the button on the remote transmitter. Does the HomeLink indicator (LED) blink after 10 secs?

YES

3. Press and hold the programmed HomeLink button for about a sec. Does the device (garage door opener) work?

YES

Training Complete

5. Press and hold the HomeLink button again. The remote-controlled device should operate.

Training Complete

NO

a. Press and hold the remote and the HomeLink button at the same time. Then, while continuing to hold the HomeLink button, press and release the button on the remote every 2 secs. Does the LED blink within 20 secs?

YES

4. Press and hold the HomeLink button again.

HomeLink LED is on.

HomeLink indicator blinks for 2 secs, then remains on.

a. The remote has a rolling code. Press the "learn" button on the remote-controlled device (e.g. garage door opener).

b. Within 30 secs, press and hold the programmed HomeLink button for 2 secs.

NO

To retrain a button or erase codes, see the Owner's Manual at [owners.acura.com](http://owners.acura.com) (U.S.) or [www.acura.ca](http://www.acura.ca) (Canada). If you need help, call HomeLink at (800) 355-3515 or visit [www.homelink.com](http://www.homelink.com).