


Multi-Information Display

Main Display

Roll the multi-function steering wheel controls to change the display.



Lower Displays

Press the **TRIP** button to change the display.

