


VISUAL INDEX


Steering Wheel and Nearby Controls



1. Lights/Turn Signals
2. Wipers/Washers

3. Horn
4. Brightness Control

Dashboard and Nearby Controls




- | | |
|-----------------------------|----------------------------------|
| 1. ENGINE START/STOP button | 5. Driver Information Interface |
| 2. USB Port | 6. Electric Parking Brake Switch |
| 3. Hood Release Handle | 7. Hatch Release Button |
| 4. Hazard Warning Button | Fuel Fill Door Release Button |

INSTRUMENT PANEL

Driver Information Interface

Roll the right selector wheel to change the display.



* Not available on all models

Lower Displays

Press the **TRIP** button to change the display.

