

Wi-Fi Connection

You can connect the audio system to the Internet using Wi-Fi and browse websites or use online services on the audio/information screen. If your phone has wireless hotspot capabilities, the system can be tethered to the phone. Use the following steps to setup.

1. Select Home.
2. Select Settings.
3. Select Bluetooth/Wi-Fi.
4. Select the Wi-Fi tab.
5. Select Wi-Fi On/Off Status, then On.
6. Select Wi-Fi Network List.

Make sure your phone's Wi-Fi setting is in access point (tethering) mode.

Select the phone you want to connect to the system.

If you do not find the phone you want to connect in the list, select Scan.



AUDIO AND CONNECTIVITY

7. Select Connect.

If needed, enter a password for your phone and select OK.

When the connection is successful, the Wi-Fi icon is displayed on the top of the screen.

8. Press the Home button to go back to the home screen.

