


Homelink® Universal Transceiver

Program your vehicle to operate up to three remote-controlled devices around your home (such as garage doors, lighting, or home security systems) using the buttons on the bottom of the rearview mirror.



■ Training a Button

Park near the system you want to program, and follow the instructions.

1. Position the remote transmitter you wish to link 1 to 3 inches (3 - 8 cm) from the Homelink® button you want to program.

2. Press and release the desired Homelink button. Is the Homelink indicator (LED) *slowly flashing orange*?

YES

- 3a. Hold the button on the remote transmitter. Does Homelink indicator (LED) change from *slowly flashing orange to rapidly flashing green or continuously on green*? The process should take less than 60 seconds.

4. Press and hold the programmed Homelink button for about a second. Does the device (garage door opener) work?

YES

Training Complete

6. Press and hold the Homelink button again. The remote-controlled device should operate.

Training Complete

NO

- 3b. Canadian Garage Door Opener

A. Press and release the Homelink button. Press, hold and release the button on the remote every 2 secs. Does the Homelink indicator (LED) change from *slowly flashing orange to rapidly flashing or continuously on green*? The process should take less than 60 seconds.

5. Press and hold the Homelink button again.

Homelink LED is *continuously on green*.

Homelink indicator *rapidly flashes green*.

- 5a. The remote has a rolling code. Press the "learn" button on the remote-controlled device (e.g. garage door opener).

- 5b. Within 30 secs, press and hold the programmed Homelink button for 2 secs.

To retrain a button or erase codes, see the Owner's Manual at owners.acura.com (U.S.) or www.acura.ca (Canada). If you need help, call Homelink at (800) 355-3515 or visit www.homelink.com.