HOMELINK®

Program your vehicle to operate up to three remote-controlled devices around your home, such as garage doors, lighting, or home security systems.

Training a Button

1 Position the remote transmitter you wish to link 1–3 inches from the HomeLink button you want to program.

2 **Press and hold** the desired HomeLink button and the button on the remote transmitter.

Does the HomeLink indicator (LED) blink at a faster rate after about 10 seconds?

NO → **a** **Press and hold** the button on the remote and the HomeLink button at the same time. Then, while continuing to hold the HomeLink button, **press and release** the button on the remote every 2 seconds.

Does the LED blink at a faster rate within 20 seconds?

NO → repeat from **1**

YES → repeat from **2**

YES → **3** **Press and hold** the programmed HomeLink button for about a second.

Does the device (garage door opener) work?

NO → **4** **Press and hold** the HomeLink button again.

HomeLink indicator flashes for 2 seconds, then remains on.

a The remote has a rolling code. **Press** the "learn" button on the remote-controlled device (e.g., garage door opener).

b Within 30 seconds, **press and hold** the programmed HomeLink button for 2 seconds.

5 **Press** the programmed HomeLink button again; the remote-controlled device should operate.

YES → **Training complete**

HomeLink LED remains on.

If you have any problems programming HomeLink, see the owner's manual included with the device you are trying to program, call HomeLink at (800) 355-3515, or visit *www.homelink.com*.