SMS Text Messaging and E-Mail*1

Certain phones can receive and send text messages and e-mails while paired and linked. Standard message rates apply. This feature is limited while the vehicle is moving. Visit *handsfreelink.com (US)* (U.S.) to check phone compatibility. Canada customers can phone (855) 490-7351 for any HandsFreeLink® related inquiry.

1. A pop-up appears and notifies you of a new text or e-mail message.
2. Rotate the selector knob to select Read to listen to the message, then press the selector knob.

   The text or e-mail message is displayed. The system automatically starts reading out the message.
3. To discontinue the message read-out, press the selector knob.

**1 - If equipped*